GNOME-P

Miniature digital stereo recorder

STC-H368

Guide to install driver
for Windows 7 x32/64

Speech
Technology
Center

ABSTRACT

Thank you for purchasing the **Gnome-P** miniature digital recorder! We hope that our software will improve the quality of your tasks accomplishment.

Before getting started, read this User's Guide (then – manual) carefully.

We welcome your feedback, questions and concerns regarding the **Gnome-P** product. If there are any questions concerning the use of the **Gnome-P** product, please contact the Speech Technology Center technical support service.

You can contact the technical support service by:

Saint-Petersburg, Russia
e-mail: support@speechpro.com
tel: (7) (812) 325-8848
fax: (7) (812) 327-9297

Moscow, Russia
e-mail: kdo@speechpro.com
tel: (7) (495) 623-5505
fax: (7) (495) 623-5517

via our official web-site: http://www.speechpro.com.

To improve our help, please be ready to provide the following information:

- name and version of the program;
- problem description;
- computer configuration;
- name and version of the operating system.

The manufacturer keeps the right to introduce any changes regarding the improvement of the product design into the manual without the notification. These changes can be found in a new edition of the manual or downloaded from the STC official website: http://www.speechpro.com.

We welcome your feedback, questions and concerns regarding our products. Please contact the offices of our company or regional dealers.

Quality Management System has been developed, implemented and now is used successfully in Speech Technology Center. It corresponds with ISO 9001-2008; our company has certificate of conformity, issued by the independent international certification company Det Norske Veritas.

Any part of this publication may not be reproduced, transmitted, stored in a retrieval system or translated into any language in any form or by any means, without the written permission of Speech Technology Center, Ltd.

CONTENTS

INTRODUCTION 4
General 4
Manpower requirements 4
Typography conventions 5
Copyright 6
1 GENERAL INFORMATION 7
1.1 About the system and the producer 7
1.2 Technical support 7
2 DRIVER INSTALLATION 8
3 SOUND MANAGER SOFTWARE INSTALLATION 10
4 DRIVER UNINSTALL 17
5 SOUND MANAGER GNOME-P UNINSTALL 18
6 TROUBLE SHOOTING 19

INTRODUCTION

General

The current software designed by Speech Technology Center (STC) is intended for users of the **Gnome-P** miniature digital recorder (then – recorder). Digital stereo voice recorder is designed for high-quality audio recording in real-life noisy conditions.

This User Guide contains information on how to (un)install the driver of the recorder and the Sound Manager Gnome-P.

This paper does not replace academic, reference books and manuals from the manufacturers of the operating system and common software.

Manpower requirements

Staff, producing the installation of the **Gnome-P** product, should have professional skills to (un)install the software.

Typography conventions

The following typographic conventions are used in the manual:

Font	Description
Normal	Body text of the manual
Italic	The first appearance of a *term*. Meaning of the term is explained here or in the appendix. Also it is used to attract *attention* or to make up notes.
Bold	Names of **software components** and interface elements (**headings, buttons**, etc.).
BoldItalic	Names of ***files*** and ***paths*** to them.

Menu selection is marked with an arrow →, i.e. the combination **Menu→Command** should be understood as following: select **Menu** and then find the item **Command**.

The word combination «press the button» means: «to place the mouse cursor on button and click».

To indicate the importance of any information, the following comments and notes are used in the manual:

Note: Useful information

Warning: Important information

Caution: Essential instructions which are obligatory to be fulfilled to prevent any fatal error in the system functioning.

Copyright

Gnome-P is trademark of Speech Technology Center Ltd. All rights reserved.

All other companies and products mentioned in the manual are property of their respective owners.

1 GENERAL INFORMATION

1.1 About the system and the producer

Name	Miniature digital stereo recorder **Gnome-P**
Conditional name	STC-H368
Producer	Speech Technology Center, Ltd.
Postal address	Russia, 196084, St. Petersburg, 4 Krasutskogo str.
Phone	(7) (812) 325-88-48
Fax	(7) (812) 327-92-97
Technical support:	
E-mail	support@speechpro.com
Website	http://www.speechpro.ru/support

1.2 Technical support

If you encounter any technical problems, please, contact our technical support service.

Please, when you address to the service, be sure to provide the following information:

- Name and version of the program;
- Problem description;
- Computer type and configuration;
- Name and version of the operating system.

2 DRIVER INSTALLATION

Connect the **Gnome-P** recorder to a PC using the USB-cable and insert the installation disk into the drive.

The device **Gnome-P** will appear in the **Other devices** category in the **Windows Device Manager**.

To launch **Device Manager**, from the **Start** menu click **Control Panel**. In the **Control Panel** window click **Device Manager**.

There are "amd64" for 64-bit systems and "i386" for 32-bit systems in the "Drivers" folder in the installation disk. Please select the driver that conforms to your PC OS capacity from the installation disk (Figure 1).

⚠ This step should be taken with special attention!



Figure 1– Gnome-P drivers in the installation disk

STC Gnome-P driver will be installed onto your PC (Figure 2).



Figure 2– Driver installation window

After installation you should restart your system for the configuration changes take effect. Click **Yes** to restart (Figure 3).


STC gnome driver
You must restart your system for the configuration changes made to STC gnome driver to take effect. Click Yes to restart now or No if you plan to manually restart later.
Yes
No

Figure 3– "STC gnome driver" dialog box

After successful driver installation, the recorder will appear as the **GNOME-R Portable recorder** in the **Universal Serial Bus controllers** category or the **USB controllers** category in the **Device Manager**.

Driver installation process is completed; you should install **Sound Manager Gnome-P** software.

3 SOUND MANAGER SOFTWARE INSTALLATION

Installation of general and special software, which are in the delivery **Gnome-P** set, is performed by a complex installer. To install the **Gnome-P Sound Manager** software, run the ***Setup.exe*** file located in the root directory on the distribution disk.

The distribution disk contains the additional software components. The Setup Wizard will automatically determine their availability on the computer and if one of them lacks, the program offers to install it (Figure 4).

If any program has already been installed, it doesn't need to be reinstalled and the previously installed components will not be displayed.

Click the **Install** button to proceed (Figure 4). Installation procedure starts (Figure 5).



Figure 4– Installing prerequisites window


Microsoft Visual C++ 2005 Redistributable - KB2467175
Please wait while Windows configures Microsoft Visual C++ 2005 Redistributable - KB2467175
Time remaining: 1 seconds
Cancel

Figure 5– Microsoft Visual C ++ 2005 Redistributable installation process

If the additional software components have been already installed, the main window of the custom installation software will appear. Click the **Gnome-P Installation** option (Figure 6).



Figure 6 – Main window of the installation program

In welcome window (Figure 7) click **Next>** and follow instructions of the Installation Wizard appearing on the screen.


Gnome-P 1.01.152 Setup
Welcome to the Gnome-P 1.01.152 Setup Wizard
The Setup Wizard will install Gnome-P 1.01.152 on your computer. Click Next to continue or Cancel to exit the Setup Wizard.
< Back
Next >
Cancel

Figure 7 – "Welcome" window

Please enter information about the user and click **Next>** (Figure 8).



Figure 8 – User registration

Read the license agreement, select "I accept the terms in the License Agreement" and click **Next>** (Figure 9).


Gnome-P 1.01.152 Setup
End-User License Agreement
Please read the following license agreement carefully
END-USER LICENSE AGREEMENT for STC SOFTWARE
You have purchased the software product ("SOFTWARE PRODUCT" OR "SOFTWARE") produced by the Speech Technology Center (herein after referred as STC). The SOFTWARE PRODUCT includes computer software, the associated media, any printed materials, and any "online" or electronic documentation. By installing, copying and otherwise using the SOFTWARE PRODUCT, you agree to be bound by the terms of this EULA. If you do not agree to the terms of this EULA, Speech Technology Center is unwilling to
I accept the terms in the License Agreement
I do not accept the terms in the License Agreement
< Back
Next >
Cancel

Figure 9 – "End-User License Agreement" window

Select the **Sound manager** component to be installed on a PC by clicking on the icon in the component tree.

If necessary, change the path location of the program file using the **Browse…** button.

Click the **Disk Usage** button to show the information about free space on hard disks.

Click **Next>** to proceed (Figure 10).


Gnome-P Setup
Custom Setup
Select the way you want features to be installed
Click the icons in the tree below to change the way features will be installed.
Sound manager
Sound manager
This feature requires 32 MB on your hard drive.
Location:
C:\Program Files\Speech Technology Center\Gnome-P\
Browse...
Disk Usage
< Back
Next >
Cancel

Figure 10 – "Custom Setup" dialog box

If necessary, create a program shortcut on the desktop or/and in program menu to quick launch of the program and click **Next>** (Figure 11).


Gnome-P 1.01.152 Setup
Shortcuts creation
Choice of the location of created shortcuts
Choose the locations of shortcuts for quick launch of the program.
Create shortcut on desktop
Create shortcut in program menu
< Back
Next >
Cancel

Figure 11 – "Shortcuts creation" dialog box

Review the installation settings. If you want to change them, click the **Back** button. To start the installation program on your PC, click **Install** (Figure 12). Installation procedure starts (Figure 13).


Gnome-P 1.01.152 Setup
Ready to Install
The Setup Wizard is ready to begin
Click Install to begin the installation. If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
Program location: C:\Program Files\Speech Technology Center\Gnome-P\
Company:
User: stc
< Back
Install
Cancel

Figure 12 – "Ready to Install" dialog box



Figure 13 – "Installing Gnome-P" dialog box

To complete the installation program, click **Finish** (Figure 14).



Figure 14 – "Completing the Gnome-P Setup Wizard" dialog box

On completion of the installation, the main installation window opens. Now it has the string "**Gnome-P is already installed**" (Figure 15).

Click **Exit** to exit the Setup Wizard program.



Figure 15 – Main installation window of Gnome-P

4 DRIVER UNINSTALL

To uninstall the driver, launch the **Device Manager**, right-click on the **GNOME-R Portable recorder** and from the context menu click **Uninstall** (Figure 16).



Figure 16 – Context menu of the "GNOME-R Portable recorder" device

In the **Confirm Device Uninstall** dialog box select the **Delete the driver software for this device** check box and click **OK** (Figure 17).

Confirm Device Uninstall
GNOME-R Portable recorder
Warning: You are about to uninstall this device from your system.
Delete the driver software for this device.
OK
Cancel

Figure 17 – "Confirm Device Uninstall" dialog box

After successful driver uninstallation you should restart your computer.

5 SOUND MANAGER GNOME-P UNINSTALL

To uninstall **Sound Manager Gnome-P**, from the **Start** menu click **Control Panel**. In the **Control Panel** window click **Programs and Features** (Figure 18). In the **Programs and Features** window, select **Gnome-P** from the list and then click **Uninstall**. The program will be uninstalled (Figure 19, 20).


« All Control Panel Items ▸ Programs and Features
Search Programs and Features
File Edit View Tools Help
Control Panel Home
View installed updates
Turn Windows features on or off
Uninstall or change a program
To uninstall a program, select it from the list and then click Uninstall, Change, or Repair.
Organize
Uninstall
Repair
Uninstall this program.
Name
Firebird 2.5.0.26074 (Win32)
Gnome-P
Microsoft .NET Framework 4 Client Profile
Microsoft .NET Framework 4 Extended
Microsoft Office 2003 Web Components
Speech Technology Center Product version: 1.01.152
Help link: http://speechpro.ru/rus/techsupport/

Figure 18 – "Programs and Features" dialog box

Figure 19 – Preparing to remove Gnome-P



Figure 20 – Gnome-P removing process

6 TROUBLE SHOOTING

Error messages may occur during driver's installation or upgrade. They are as follows: "This driver cannot be installed on the computer" or "Installable driver is not compatible with this Windows operating system (OS)".

These errors may occur in the following cases:

– While installing, the driver is selected that does not conform to OS capacity;

– Before installing the driver of 1.0.0.127 version and above, attempts to install earlier versions of the drivers, which are not designed to run on Windows 7, were made.

In case of the errors firstly make sure that during the installation process the driver was correctly selected and driver's capacity corresponds to the PC OS.

If the driver is selected incorrectly, you should restart the driver installation process and then select the driver of the appropriate OS capacity.

If the driver is selected correctly and there are errors while installing the driver, you should uninstall the driver (refer to 4) and then try to install it again.